



Clip T Series

Thermal Imaging Attachment


Operating Manual

1. Description

Clip T Series is one of the most compact and cheapest thermal imager attachment for sights on the market, which is mainly used with day riflescope and low cost, low power consumption and miniaturization.

2. Components

1. Objective Lens
2. Power (P) Button
3. Type-C Interface
4. Menu (M) Button
5. Battery Compartment
6. Eyepiece Locking Ring
7. Eyepiece Interface



3. Features

- 12μm thermal imaging detector
- High image quality
- The most compact size
- Ultra light weight
- Low power consumption and long endurance
- HD resolution OLED Display
- IP67 Rating

4. Battery Installation

- Remove the battery cap by unscrewing it counter clockwise
- Insert a CR123 with positive pole inwards
- Return battery cap into housing, screw clockwise until tight


Tips:

- > Avoid removing the O shape seal ring.
- > Notice the poles of battery placed in right directions.

5. Mounting Clip T on a Daylight Scope

Before installing Clip T onto your daylight device, the following preparations should be made:

- Select an **adaptor fixture (9)** with an insert of the required diameter depending on the outer diameter size of the objective lens of your daylight device.
- Prepare a **thread adapter insert (8)** that can match with the thread interface of Clip T eyepiece and metal adaptor fixture.



Installation

- Install the **threaded adapter insert (8)** to Clip T by rotating clockwise along the thread.
- Rotate the **eyepiece locking ring (6)** counterclockwise to lock the **adapter insert (8)**.
- Install the **threaded insert (8)** fully into the **adapter fixture (9)**.
- Install fully the **adapter fixture (9)** with Clip T onto the **objective lens (10)** of your daylight device.
- Pull the **handle (11)** on the **adapter fixture (9)** to lock it firmly on your daylight device. Check that the **adapter fixture (9)** is snugly fitted onto the **objective lens (10)**.
- If there is space or if the lever cannot reach the locking position, adjust the locking screw with the hex-nut wrench to ensure that the adapter fits tightly the objective lens.

Tips:

- > Clip may be installed in wrong position while tighten on screw thread, change its position by adjust eyepiece locking ring.
- > The eyepiece interface thread (7) of Clip T series is M30*1.0;
- > A thread adapter ring with M52*0.75 thread interface will be presented in the package of Clip T;

6. Menu/Status Bar Icons


	White hot
	Black hot
	Red hot
	Color
	Display lightness
	Manual Calibration
	Automatic Calibration
	USB mode
	Battery Indicator

7. Operations

7.1 Switch On/Off

Press and hold the **P button(2)** to turn on the device. Waiting for 3 seconds to enter the home interface.

Press and hold the **P button (2)** until the shutdown countdown is 0, release the button to turn off the device.



7.2 Standby Mode

Press and hold **P button(2)** until the countdown appears, release the button within 3s countdown to activate the standby mode.

Short press **P button(2)** again to exit standby mode.

7.3 Status Bar

In the home interface, there are system information hints at the bottom of the screen including: Palette, Screen Brightness, Calibration mode, Battery status etc.

7.4 Calibration

In the home interface, short press the **P button(2)** for shutter calibration.

7.5 Image Movement

In home interface, press and hold the **P button(2)** and **M button(4)** to enter into the image movement interface.

- The movement distance and direction on X & Y axis appear on the interface.
 - > Short press **P button(2)** to move upward one pixel.
 - > Long press **P button(2)** to move upward ten pixels.
 - > Press and hold **P button(2)** constantly to move upward continuously.
 - > Press the **M button(4)** to move downward, and the adjustment mode is the same as steps above.
- Press **P button(2)** and **M button(4)** simultaneously to switch the movement directions.
- While switched to horizontal movement, press **P button(2)** to move towards left and **M button(4)** to move towards right. Movement method is same as vertical on Y-axis.
- Long press the **P button(2)** and **M button(4)** simultaneously to save calibration data. Once saved, the device will exit this interface after 2s.

Tips: While idle, the device will exit image movement interface in 30s, without saving.

7.6 Shortcut Menu

In the home interface, short press the **M button(4)** to enter shortcut menu. Options in Shortcut menu are as follow: Palette - Screen Brightness - Calibration - Exit.

- **Palette:** press **P button(2)** briefly to switch between White Hot - Black Hot - Red Hot - Pseudo Colour.
- **Screen Brightness:** Press **P button(2)** briefly to adjust the screen brightness among four levels.
- **Calibration:** short press **P button(2)** to switch between Automatic (A) mode and Manual (M) mode.



7.7 Type-C Mode

In the home interface, while connected with Type C cable, press and hold the **M button(4)** and meanwhile quickly press **P button(2)** five times to activate Type C Mode for updating firmware.

Repeat previous steps or plug out USB cable to exit Type C mode.

8. Cautions

- Do not look directly at high radiation sources (such as solar).
- Avoid contact lens with sharp items.
- Please use standard battery. Don't throw used batteries anywhere or into fire.
- Avoid to expose in high temperature environment (>60°C).
- Avoid short circuit product.
- Avoid put the device into fire.

9. Maintenance

- Polish the device with soft cloth by dipping certain amount of alcohol.
- For optical glass parts (such as eyepiece lens and objective lens), blow dust first, and then wipe slightly with charcoal pen or absorbent cotton swab that dipping unmetethylated alcohol.

10. Customer Service

+86-400-998-3088	+86-535-3410604
24h Hotline	Fax

infirayoutdoor@infiray.com	
Email	www.infirayoutdoor.com

Specifications

Model	CTP13
Microbolometer	
Resolution, pixels	256×192
Pixel size, μm	12
NEDT, mk	≤40
Frame refresh rate, Hz	25
Optical Specifications	
Objective Lens, mm	13
Field of view, degree	13.5×10.1
Magnification	1×
Detection range, m (Target size: 1.7mx0.5m, P(n)=99%)	675
Display	
Type	0.39" OLED
Resolution, pixels	1024×768
Operational Specifications	
Battery type	CR123(3.7V)×1
Power consumption, mW	About 800
Max. battery life(t=25 °C), h	3.5
Operation temperature, °C	-20 ~ +50
IP Rating	IP67
Dimension, mm	79×52×46
Weight(without battery), g	≤140
USB Type	Type-C
Eyepiece Interface	M30×1.0

- Improvements may be made to the design and software of this product to enhance its user features.
- Technical parameters of the device may be improved without prior notice of the customer.

Infiray Latvija

Tel: +371 270 22 037

Email: info@infiray.lv

Web: www.infiray.lv

Add.: Brīvības iela 204b, Rīga, Latvija, LV-1039

Add.#2: Kuldīgas šoseja 6, Druva, Saldus pag., LV-3862



Infiray Latvija

